

# INSTALLATION GUIDE

## Required Tools

The following tools will be required to properly install ClearSight® Vegetation Control Matting:

- 25' tape measure
- Utility knife with extra blades
- Chalk Line
- Caulk gun



## Dry Lay/Adhesive Application Cutting and Fitting

1. After the excavation work has been completed, roll out the ClearSight® in the designated area.
2. Mark the run for the guardrail posts with a tape measure and chalk lines onto the ClearSight®.
3. Unload the steel posts near the work site.
4. Lay the rails out at the work site on top of the ClearSight®.
5. Straighten the rails near the position on the ClearSight® where they will be installed.
6. Hammer the posts into the ground straight through the marked position on the ClearSight®.
7. Adhere each roll to the next roll by overlapping approximately 4"-6" of material and using an approved SDS modified bitumen adhesive.
8. Seal around each post where they puncture the ClearSight® using an approved SDS modified bitumen adhesive.
9. Hang the rails onto the posts.
10. Tighten all the bolts.

## Handling and Storage

1. ClearSight® should be delivered to the job site in its original, unopened packaging with all labels intact and stored appropriately to prevent damage.
2. Inspect the product before installing. Under our 10 year limited warranty, U.S. Rubber is not responsible for any damage due to transportation, improper handling, alteration, abuse or negligence or any accidental or consequential damage, including, but not limited to, a labor claim for installation or removal of the product with visually apparent defects.